

# Important Information for Kodak Kiosk Operators

Kodak Alaris is introducing a new, more environmentally friendly, Small Format Media with a companion Firmware update

**This Firmware upgrade is REQUIRED for the use of the new print kits, which are going to be released early in 2015**

- Provides firmware change to improve image quality now and will accommodate new print size options in the future.
- New error codes and other diagnostic information is being added to better service printers
- Product launched on a Stock turnover basis
- Also available for download at :  
**[www.kodak.com/go/printerupdates](http://www.kodak.com/go/printerupdates)**

•**NOTE: This new firmware update is compatible with your existing print kits, however, the new print kits MUST have the new firmware installed to use.**

We will endeavour to send this firmware out with your next order for print kits, but if you have not received it by January 30, you should contact us at 1-888-445-9097 and request a kit be sent to you

**Kodak** alaris

**Hydes**  
DISTRIBUTION

# Important Upgrade for Kodak Kiosks

Easy identification of the new media by the following changes:

- Color of the donor belly band has been changed from yellow to **PURPLE**
- A stuffer sheet will be included in each case of media for the first 90 days of production.
- The packaging case label will exhibit a starburst with “NEW” callout



## Important—New Media for Your KODAK Printer!

EN

Kodak has a new generation of media to replace the existing media for the KODAK Photo Printer 6800/6850 and the KODAK 7000/7010/7015/605 Photo Printer. Before you load the new media into your KODAK Printer, you **must** verify that the required firmware is installed. Once the firmware is installed, both the old and new media will work in your printer. Do the following to check the firmware version on each system connected to a KODAK Printer.

1. If you have:

Picture Kiosk	KODAK Adaptive Picture Exchange
a. Select <i>Setup</i> . Enter the password if necessary.	a. Select <i>Setup</i> . Enter the password if necessary.
b. Select <i>Diagnostics</i> .	b. Select <i>Diagnostics</i> .
c. Select <i>Application Health Check</i> .	c. Select <i>Application Health Checks</i> .

2. Verify that “KODAK 605/68XX/70XX Printer FW Update - 2014” appears on the list of installed software components.
3. If it does not appear, you must install the “KODAK 605/68XX/70XX Printer FW Update - 2014” Firmware CD.
4. If you cannot locate your firmware CD, go to [www.kodak.com/go/printerupdates](http://www.kodak.com/go/printerupdates) to download the required firmware and installation instructions or contact your local service representative.
5. If you have difficulties installing the firmware or media in your KODAK Printer, contact your local service representative.

If your KODAK Printer is not connected to one of the systems above, go to [www.kodak.com/go/printerupdates](http://www.kodak.com/go/printerupdates) to download the required firmware and installation instructions.

## Note the new cat number

1

Kodak

6 x 8 in.  
15.2 x 20.3 cm

New!  
Nouveau!

Photo Print Kit 6800/ 6R

To make 750 – 4 x 6 prints / 375 – 6 x 8 prints  
 Para hacer 750 – 4 x 6 impresiones / 375 – 6 x 8 impresiones  
 Per fare 750 stampe 4 x 6 / 375 stampe 6 x 8  
 Para faire 750 tirages 4 x 6 / 375 – tirages 6 x 8  
 750 枚の写真(4x6)をプリント  
 375 枚の写真(6x8)をプリント  
 可列印 750 張 6吋照 / 375 張 8吋照

TN/MS/WR Licensed from Eastman Kodak Company; Kodak  
 Kodak Alaris Inc., 2400 Hazel Road Blvd., Rochester, N.Y. 14615 © 2014 Kodak Alaris Inc.

1122233

CAT 141 9597

6 00 41771 41959 4

6R

Do not remove this label until step ②

1

2

3

4

6x8 in. / 15x20 cm